

How to Mount Nanhai Projection Films

To apply the adhesive-backed Nanhai Films to windows, glass, acrylic or polycarbonate substrates, have the following items ready to use:

Nanhai series cut sheet to size

Spray bottle with water

Rubber-blade squeegee

Dry, soft cloth

Tape to mark the boundaries of the Nanhai Film if it is smaller than the substrate

1. Thoroughly clean the glass or plastic substrate of dirt, dust or oils using mild detergent if necessary and squeegee the excess soap/water from the substrate.
2. Use the tape to mark the area that the film will be applied (if the film is smaller than the substrate.)
3. Peel the release film from the Nanhai Film half way back and spray the adhesive-side of the film and the surface of the substrate with water.
4. Place the Nanhai Film carefully on the substrate while aligning the edges to the tape.
5. Remove the water and any air bubbles with the squeegee blade by gently squeezing the water from the center of the film toward the edges.

NOTE: The squeegee may glide more smoothly over the top of the film if it is also sprayed with water.

6. Repeat Steps 3 to 5 for the other half of the film.

NOTE: Make sure to peel the release film evenly from both corners to prevent the film from creasing or folding over on itself.

7. Remove the excess water with a dry, soft cloth.
8. Remove the tape.
9. For some classic types, remove protective cover after mounting.